

## Bathroom Doorstop

Submitted by Richard Cox (r.w.cox@ieee.org)

September 2006

Keep the bathroom door open.



APPROX. MODIFICATION TIME: 15 min.

### PARTS LIST

All prices are pre-tax.

The doorstop above is National Hardware Co. N243-832, 4" Kick-down Stop. This item is usually available at most good hardware stores like True Value, Ace, Lowe's, etc.	~ \$5
APPROX. TOTAL COST OF PARTS	~ \$5

### TOOLS

- tape measure
- pencil
- awl or drill to make pilot holes
- screwdriver that matches the screw heads

### INSTRUCTIONS

Install the doorstop approximately 2 ½" in from the left side and 1 ¾" up (center of screws) from the bottom of the door when viewing the inside of the door. Hold the stop in place and try it out before actually mounting it. The supplied screws might be too long, so check before you start and replace with shorter ones, if needed.

Updated

Thursday, 14 September, 2006