

Window Shade Standoff

Submitted by **Bob Lutz** (ralutzpe@aol.com)

August 2004

The window shades can be moved 1/2" away from the side windows so they will no longer interfere with the window-opening mechanisms.

APPROX. MODIFICATION TIME: .5 hours

PART LIST

All prices are pre tax.

See current TechRally Schedule for availability and price of ModKit.

PER WINDOW	
Two 1/2" long plastic, white, standoffs	<\$2
Two screws, 1/2" longer than provided in RV	<\$2
APPROX. TOTAL COST OF PARTS - PER WINDOW	<\$5

INSTRUCTIONS

At a hardware store, (like Lowe's or Home Depot), purchase 1/2" long plastic, white, standoffs. Also, take a screw from the RV and match it up with one like it, except 1/2" longer.

Replace the existing screw with the longer screw and place the standoff between the bobbin and the wall to stand the bobbin off 1/2".

It looks good and provides clearance so the shades slide up and down without hitting the window-opening wheel. It's made opening my shades a shade easier.

Updated
Wednesday, September 1, 2004