

## RV QUICK REFERENCE CHART

**Models 595-0, 661-5, 802-3, 843-0, 860-0, 861-0, 862-1**

	595-0	661-5	802-3	843-0	860-0	861-0	862-1
DESCRIPTION	IM-72	NP-30G	Impact-36G	IM-72	IM-52	IM-66	QP55-G
<b>Generac Genuine Replacement Part Numbers</b>							
Engine	79204	A2467B	A2467B	79579	79204	79204	A7629
Oil Filter	70185	70185	70185	70185	70185	70185	70185
Air Filter	73123	78601	78601	73123	73123	73123	73111
Pre-cleaner	69341	78602	78602	69341	69341	69341	81646
Fuel Filter	87769	86311	86311	87769	87769	87769	87769
Spark Plug	72347	72347	72347	72347	72347	72347	72347
Spark Plug Boot	73132	73132	73132	73132	73132	73132	73132
V-Belt	75216	-	-	75216	75216	75216	75216
Stator	92848H	A5898	A5898	A2592H	20765H	20766H	A5646H
Rotor	80095H	-	-	80095H	77005H	77004H	A5649H
Magnetic Housing Ass'y	-	A5892	A5892	-	-	-	-
Ignition Assembly	-	A9178	A9178	-	-	-	92572
Contactora, Starter	86729	86729	86729	86729	86729	86729	86729
Starter	75255	99948	99948	75255	75255	-	21544
Oil Switch	99236	77667	77667	99236	99236	99236	-
Oil Pick Up Screen	-	86714	-	-	-	-	-
Auto Choke Assembly	93690	86734	91306	93690	93690	93690	A6239
Cap & Dipstick Ass'y	74958	89263	89263	74958	74958	74958	A4970
Fuel Pump	90475	90475	90475	90475	90475	90475	90475
Carburetor	73112B	90881A	90881A	73112B	73112B	73112B	A5305P
LP Regulator	-	-	-	-	-	-	-
Fuel Shut Off Solenoid	89870	-	-	89870	89870	89870	-

Hall Sensor Mod Ass'y	-	86697	86697	-	-	-	-
Genister, PCB Assembly	-	87992	87992	-	-	-	-
Stepper Motor/Speed Ctl	-	92059	92059	-	-	-	-
Rectifier Assembly	-	-	-	-	-	-	-
Regulator Assembly	92934	-	-	92934	92934	92934	-
Thermal Switch	-	94090	94090	-	-	-	-
Circuit Breaker	82081	-	-	A2598	74968	82081	90144
Circuit Breaker	54502	90145	90145	54502	53623	54502	90145
Brush Holder Assembly	66386	-	-	66386	66386	66386	66386
Gasket, Air Cleaner	66480	-	90536	66480	66480	66480	90970
Gasket, Carb/Manifold	-	78631	-	-	-	-	-
Gasket, Oil Filter Adater	-	87478	87478	-	-	-	86999
Gasket, Oil Fill	A5508	-	-	A5508	A5508	A5508	-
Gasket, Exhaust Flange	77643	89476	89476	77643	77643	77643	90239
Gasket, Manifold/Head	-	90051	90051	-	-	-	-
Gasket, Oil Drain Plug	-	94643	94643	-	-	-	-
Gasket, Carburetor	69379	96459	96459	69379	69379	-	89228

Gasket, Filter Adapter	68548	-	-	68548	68548	68548	-
Gasket, Air Slide Pan	75229	-	-	75229	75229	75229	-
Rubber Mount	46911	38353	38353	46911	46911	46911	46911
Skid Rubber Mount	72391	-	-	72391	72391	72391	-
Vibration Mount	82737	-	66443B	82737	82737	82737	-
Hose, Breather	-	89062	89062	-	-	-	-
Remote Cable Assembly	75244	75244	75244	-	75244	75244	-
Muffler Assembly	-	86731A	86731A	-	-	-	A6095
Screen, Spark Arrest	-	89680	89680	-	-	-	-
Flywheel	73130	94586	94583	73130	73130	73130	SRV-91222D
Bearing Carrier, Upper	72379B	-	-	72379B	72379B	72379B	72379B
Bearing Carrier, Lower	75995	-	-	75995	75995	75995	-
Pulley, Alternater	73106G	-	-	73106G	-	73106F	73106B
Owner's Manual	98699	A9400	A9398	A2624	98699	98699	A9422
Installation Manual	A3901	-	-	-	A3901	A3901	-
PCB, CCG	-	A3369	A3369	-	-	-	-
Ignition Module	-	86711	86711	-	-	-	-
Triac Module	-	86275	86275	-	-	-	-
Fuse	22676	-	A9611	22676	22676	22676	-
High Temperature Switch	75281	-	-	75281	75281	75281	-

RV Control Board	92234	92234	92234	92234	92234	92234	-
Voltage Regulator	83049	-	-	83049	83049	83049	-