




**DANGER**

**Danger of electrical shock, burns or death.** Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



**CAUTION**

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- NOTES:
- ③ WIRE ROUTED THRU SIDEWALL.
  - ② WIRE ROUTED THRU ROOF.
  - ① ALL OUTLETS DOWN STREAM AND INCLUDING THIS OUTLET ARE GROUND FAULT CIRCUIT INTERRUPT PROTECTED.

(265) CODES/STANDARDS-CSA/CMVSS  
 (1B1) CODES/STANDARDS USA  
 (12D) ELECTRICAL SYSTEM 30 AMP

(12D) (1B1) (265)

COPYRIGHT 2002 WINNEBAGO INDUSTRIES, INC. **WINNEBAGO** 03 222HD

DFTR	DATE	UNSPECIFIED TOLERANCES ARE:	MATERIAL:
CHR	DATE	ANGLE DIM (X, Y)	
P E	DATE	ONE-PLACE (X, XX)	
M E	DATE	TWO-PLACE (X, XX)	
DSNR	DATE	ANGLE	
	DATE	THIRD ANGLE PROJECTION	

LAYOUT NO. TITLE: **WIRING DIAGRAM-BODY, 110V**

DIA # SCALE: NONE DO NOT SCALE DRAWING SIZE DWG NO. 141385

ALL DIMENSIONS ARE IN MILLIMETERS SHEET 1 OF 1 I E NO. 141385

REF: 137245 A | 07/23/02