



Technical Bulletin

Subject: **Use of Novelty Compact Discs in Compact Disc (CD) Players**

Group: **91**

Number: **98-02**

Model(s): **All with CD Players**

All

Date: **Apr. 6, 1998**

Condition

CD player jams or magazine will not eject.

May be caused by the use of novelty (shape) CD's which have shapes (see examples A and B) other than the intended shape for CD players.

Service

A CD revolves at high speed within the CD player. Novelty CD's can warp and may not eject from the CD player.

Note:


Most Novelty CD's come with WARNINGS: DO NOT USE IN AUTOMOTIVE CD PLAYERS.

ONLY use standard size CD's in the CD player.

Volkswagen of America, Inc. may deny warranty coverage if a CD changer fails due to improper CD usage.



◀ **Example A**



◀ **Example B**

C