

# FOR YOUR SAFETY READ BEFORE OPERATING

**WARNING: IF YOU DO NOT FOLLOW THESE INSTRUCTIONS EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.**

- A. THIS APPLIANCE DOES NOT HAVE A PILOT. IT IS EQUIPPED WITH AN IGNITION DEVICE WHICH AUTOMATICALLY LIGHTS THE BURNER. DO NOT TRY TO LIGHT THE BURNER BY HAND.
- B. BEFORE OPERATING SMELL ALL AROUND THE APPLIANCE AREA FOR GAS. BE SURE TO SMELL NEXT TO THE FLOOR BECAUSE SOME GAS IS HEAVIER THAN AIR AND WILL SETTLE ON THE FLOOR.
- WHAT TO DO IF YOU SMELL GAS
- EXTINGUISH ANY OPEN FLAME.
  - EVACUATE ALL PERSONS FROM THE VEHICLE.
  - SHUT OFF THE GAS SUPPLY AT THE GAS CONTAINER OR SOURCE.
  - DO NOT TOUCH ANY ELECTRIC SWITCH, OR USE ANY PHONE OR RADIO IN THE VEHICLE.
  - DO NOT START THE VEHICLE'S ENGINE OR ELECTRIC GENERATOR.
- CONTACT THE NEAREST GAS SUPPLIER OR QUALIFIED SERVICE TECHNICIAN FOR REPAIRS.
  - IF YOU CANNOT REACH YOUR GAS SUPPLIER OR QUALIFIED SERVICE TECHNICIAN, CONTACT THE NEAREST FIRE DEPARTMENT.
  - DO NOT TURN ON GAS SUPPLY UNTIL THE GAS LEAK(S) HAS BEEN REPAIRED.
- C. USE ONLY YOUR HAND TO PUSH IN OR TURN THE GAS CONTROL KNOB. NEVER USE TOOLS. IF THE KNOB WILL NOT PUSH IN OR TURN BY HAND, DON'T TRY TO REPAIR IT, CALL A QUALIFIED SERVICE TECHNICIAN. FORCE OR ATTEMPTED REPAIR MAY RESULT IN A FIRE OR EXPLOSION.
- D. DO NOT USE THIS APPLIANCE IF ANY PART HAS BEEN UNDER WATER. IMMEDIATELY CALL A QUALIFIED SERVICE TECHNICIAN TO INSPECT THE APPLIANCE AND TO REPLACE ANY PART OF THE CONTROL SYSTEM AND ANY GAS CONTROL WHICH HAS BEEN UNDER WATER.

## OPERATING INSTRUCTIONS

1. STOP! READ THE SAFETY INFORMATION ABOVE ON THIS LABEL.
2. SET THE THERMOSTAT TO LOWEST SETTING.
3. TURN OFF ALL ELECTRIC POWER TO THE APPLIANCE.
4. THE APPLIANCE IS EQUIPPED WITH AN IGNITION DEVICE WHICH AUTOMATICALLY LIGHTS THE BURNER. DO NOT TRY TO LIGHT THE BURNER BY HAND.
5. TURN SHUT-OFF VALVE TO "OFF". THIS FURNACE IS EQUIPPED WITH A VALVE SHUT-OFF SWITCH. WITH SWITCH IN "OFF" POSITION, GAS WILL NOT FLOW TO BURNER NOR WILL THE FURNACE OPERATE.
6. WAIT FIVE (5) MINUTES TO CLEAR OUT ANY GAS. THEN SMELL FOR GAS, INCLUDING NEAR THE FLOOR. IF YOU THEN SMELL GAS, STOP! FOLLOW "B" IN THE SAFETY INFORMATION ABOVE THIS LABEL. IF YOU DON'T SMELL GAS, GO TO THE NEXT STEP.
7. TURN ON ALL ELECTRIC POWER TO THE APPLIANCE. THESE UNITS ARE FOR USE WITH LP GAS ONLY. LP GAS IS HEAVIER THAN AIR. THEREFORE, TO BETTER CLEAR OUT ANY GAS, THE HEATER SHOULD BE OPERATED FOR FIVE (5) MINUTES WITH THE BLOWER ON AND THE GAS OFF.
8. TURN SHUT-OFF VALVE TO "ON".
9. SET THERMOSTAT TO DESIRED SETTING.
10. IF THE APPLIANCE WILL NOT OPERATE, FOLLOW THE INSTRUCTIONS "TO TURN OFF GAS TO APPLIANCE" AND CALL YOUR SERVICE TECHNICIAN OR GAS SUPPLIER.

## TO TURN OFF GAS TO APPLIANCE

1. SET THE THERMOSTAT TO LOWEST SETTING.
2. TURN OFF ALL ELECTRIC POWER TO THE APPLIANCE IF SERVICE IS TO BE PERFORMED.
3. TURN SHUT-OFF VALVE TO "OFF". DO NOT FORCE.